



DEFENDER CLEANER

GELSON®AZIENDA CON SISTEMA QUALITÀ
CERTIFICATO DA DNV
UNI EN ISO 9001




Page. 1/1

TECHNICAL DATA SHEET

Rev. 0 dated 18/03/2011

Degreaser cleaner to prepare surfaces to be treated with the nanometric system Defender 2K.

Excellent also for cleaning and removing residues before using the micrometric and nanometric pastes 1890 and 1870, because promotes the grip, and before the passage of the finishing polishes, T93, T95 and T98, because improves adhesion to the substrate and duration.

PRODUCT PREPARATION:	
	Mix well before use
PRODUCT APPLICATION:	
	Soak a cloth (Hitex 4000) in Defender Cleaner. Clean the surface with the soaked cloth, treating a surface area of approx. 0.5 m² at a time. Dry thoroughly using a dry Hitex 4000 cloth to avoid streaking.
STORAGE:	
	IMPORTANT: Store the product at a temperature > 5° C. 12 months in a cool, dry area in its original package.
PACKAGE SIZES AVAILABLE:	
Code	Package size
45780	1 l
45790	200 ml

The effectiveness of our products is based on practical experience and research carried out in our laboratory. However, we decline any responsibility for work carried out, as it is evident that the result can be strongly affected by a series of factors beyond our control.